

FIG. 1A






FIG. 2








FIG. 4




FIG. 5






FIG. 5A


**FIG. 6**




**FIG. 7**



**FIG. 8**



**FIG. 9**











FIG. 11







**FIG. 12**




**FIG. 14**






**FIG. 15**

**FIG.16**



$$\left\{ \begin{array}{l} \text{ } \end{array} \right.$$






FIG. 18








FIG. 20A(1)




FIG. 20A(2)




FIG. 20B(1)



FIG. 20B(2)




FIG. 20C






FIG. 20D


**FIG. 21**




**FIG. 22.**




**FIG. 23**







**FIG. 25**

Clamp Linkage with  $K = 50.00$  (N / mm) ,  $w = 7.00$  (mm) ,  $L = 30.00$  (mm)  
 $h = 1.00$  (mm) , Button travel = 25.82 (mm) , Button Start = 4.17 (mm)



**FIG. 26**





**FIG. 27A**

**FIG. 27B**








FIG. 27C



**FIG. 28A**



**FIG. 28B**






FIG. 28C



**FIG. 29A**



**FIG. 29B**







FIG. 29C






**FIG. 30A**




**FIG. 30B**

FIG. 30C



**FIG. 31A**



**FIG. 31B**








FIG. 31C



**FIG. 32A**



**FIG. 32B**





FIG. 32C



**FIG. 33**

